

Scenix Mixing Guide



Scenix Mural & Theme Paint

ACTIVATED – FAST CURE

Cures in 4-6 hours / Tape and Clear in 1 hour

STEP 1	Additive	4016 Cross-Linker	<ul style="list-style-type: none"> • Add 2% per volume • Mix thoroughly
STEP 2	Reducer	4012	<ul style="list-style-type: none"> • Add 2-10% per volume • Mix thoroughly & wait 10 minutes to acclimate before using • 4-hour pot-life after thinning with 4012 [or 4011]

NON-ACTIVATED

Cures in 48 hours / Tape and Clear in 4-8 hours

4013	Acetic acid version of 4012 Reducer	<ul style="list-style-type: none"> • Activating with 4016 Cross-Linker not required when thinning with 4013 or 4014 • Add 5-10% per volume
4014	Compliant reducer made with deionized water & acetic acid	<ul style="list-style-type: none"> • Mix thoroughly & wait 10 minutes to acclimate before using • 60 minute pot-life after thinning with 4013 or 4014 • Paint dries & cures faster when thinned with 4013 compared to 4014

SSR Clear [Sun Screen Resistant]

STEP 1	Additive	4015 Cross-Linker	<ul style="list-style-type: none"> • Add 2% per volume • Mix thoroughly
STEP 2	Reducer	4011	<ul style="list-style-type: none"> • Add 2-10% per volume • Mix thoroughly & wait 10 minutes to acclimate before using • 4-hour pot-life after thinning with 4011
STEP 3	Apply	Refer to SSR Technical Data Sheet	<ul style="list-style-type: none"> • Interior, apply 1 tack coat followed by 3 medium-wet coats • Absolute outdoor protection, apply as a 2-Step process <ul style="list-style-type: none"> Step 1: Apply a tack coat, followed by 2 medium coats. Allow a 6-hour min. cure time. Step 2: 6 to 24 hours after 1st application, apply 2 more medium coats. Scuffing not required.

FLEXIBLE SUBSTRATES:

Activate SSR Clear with 4016 Cross-Linker added 2% per volume, then thin with 4011 Reducer.



PO Box 120, 14 Airport Park Rd | East Granby, CT 06026
800.243.2712 | 860.653.5505 | createxcolors.com